

METRIA TP3001 DIGITAL THERMOMETER USER MANUAL

Introduction

Thank you very much for choosing the pen type thermometer. It is good for measuring food temperature and normal contact temperature testing.

The meter is easy to operating. Just push out the probe cover and install the battery, touch the object and press the ON button to measure the temperature.

Please keep the thermometer at the place that children cannot touch to avoid getting hurt, as the probe is sharp. Cover the probe after using.

Specifications

- Temperature range: -50 — $+300$ °C (-58 — $+572$ °F)
- Resolution: 0.1 °C/°F
- Power supply: 1.5V

Functions and operation

Data Hold. Press the HOLD button to hold the temperature value when measuring. Press again to start new measuring.

°C and °F selecting. Press the °C/°F button to select one of them you need.

ON/OFF. Press the ON/OFF button to turn on the thermometer. Press again to shut off it.